

C-Com[®] Affinity Plus Headset Settings



FOR SETTING	All functions are from an Off state. Press the power button and release with the appropriate buttons below
ISO restrict On	IC1 button
ISO restrict Off	IC1 and ISO buttons
Handsfree On selected button(s)	IC1 and/or IC2 and/or ISO and volume up button
Handsfree Off selected button(s)	IC1 and/or IC2 and/or ISO and volume down button
Listen-Only mode On	Volume down button
Listen-Only mode Off	Volume up button
Headset "lights-off" mode *	IC2 button

* The headset can be set up with its indicator lights off, to avoid distraction if users are in an area visible to the audience. This setting is not saved when you power off.

FOR SETTING	With the power already on...
Increase mic gain (15 steps)	Press IC2 while repeatedly pressing the up volume button
Decrease mic gain (15 steps)	Press IC2 while repeatedly pressing the down volume button